
E–ZIG ZAG STITCH WIDTH REGULATOR
F–STITCH WIDTH REGULATOR STOP
C–STITCH WIDTH LOCK
S–SNAP LOCK DARNER
H–BUTTONHOLER AND BLINDSTITCH KNOB
T–THREAD TAKE UP LEVER
L–SEWING LIGHT SWITCH (BACK)
D–HAND WHEEL
Y–PRESSER FOOT LEVER (BACK)
Signature
STITCH WIDTH
BUTTON-HOLER
5 4 3 2 1 0
STITCH LENGTH
R–FACE PLATE
M–TENSION REGULATOR
K–AIR COOLED MOTOR
G–STITCH LENGTH REGULATOR AND REVERSE BUTTON
Q–THREAD CUTTER
X–PRESSER BAR
O–HINGED BOBBIN CASE COVER
J–FEED RETURN
P–SNAP OUT RACE (UNDERNEATH)
N–PRESSER FOOT
J–DROP FEED